Created by Compulink and Racers/Promoters Peter Biondo and Kyle Seipel, TruSTART is receiving rave reviews worldwide now.

Your Compulink StarTRAK Timing System can be upgraded with the creative Patented and Trademarked TruSTART function. This function allows both RED lights on the Compulink Start Line Tree to be displayed if both competitors RED-Light. Previous timing systems up to this point have always 'locked out' the second (faster car's) RED-Light in Eliminations if the first car (slower car) leaves too soon and RED-Lights. TruSTART will display RED Lights in BOTH lanes if both competitors do in fact leave early. The least RED-Light of the two will then determine the Winner of the race, equalizing the Start Line regardless of the cars' Dial-Ins. Instead of the slower car leaving with a RED-Light and it's 'Race Over', the second car now has to leave, at which time the actual GREEN/RED light status of both cars will be displayed, creating a level playing field for all competitors. In Beta tests at both of the Bracketraces.com Spring Flings in 2016, Halloween Classics at both Firebird Raceway in Boise and Norwalk, and late season Events at Bandimere, Racers and especially Announcers loved the new function. TruSTART has finally levelled the field, and also has added some excitement to Sportsman racing

******* TruSTART Operation Modes *********

Run program TRU instead of normal program DRAG. TruSTART can be selected per Category in program CE, line 10. If TruSTART is NOT turned ON for a category, then that Category runs the same as has always been the case. If TruSTART is turned ON for that Category, then the Patented/Trademarked TruSTART mode will run in that Category. Full Tree ONLY. DO NOT RUN PRO Tree or SPLIT TREE in TruSTART mode. Also note that the Reaction Times in TruSTART mode start with the FIRST Amber, so a Racer can get up to a -1.500 R/T. Leaving earlier than the 1st Amber will result in the R/T showing 'LB1A'. Non TruSTART mode still starts the R/T at the 3rd Amber, and leaving before that will show a 'LB3A'.

Compulink TruSTART will display RED Lights for BOTH competitors both in Time Trials and Eliminations. Time Trials/Qualifying work the same as 'normal', with 2 exceptions

- 1.. Announcer Screen and scoreboards will not display Reaction Times until BOTH Cars leave.
- 2.. If one car leaves and the second car is 'late', the GREEN/RED status of the first car leaving will not reveal until the second car leaves. The first leaving car will always count down AMBER, AMBER, AMBER, GREEN regardless of the actual GREEN/RED status of that car in order to hide a possible RED Light. Note that this is the same in both Time Trials and Eliminations. After both cars have left the Start Line, the actual GREEN/RED status of both cars will be shown.

Eliminations work the same as Time Trials/Qualifying as above. Slower car will always count down AMBER, AMBER, AMBER, GREEN in order to hide a possible RED Light to the faster car. When the faster car leaves, both sides of the Tree will then display the actual GREEN/RED status of each lane. If two RED lights were to occur, then the lesser of the two REDS will receive the instant WIN Light.

Run scenarios

2 Cars GREEN Race as 'normal'

1 Car RED Non-RED car receives the instant WIN

2 cars RED Lesser of the two REDS receives instant WIN